


MULTI-ZONE ON-WALL 4 CHANNEL AMPLIFIER

Model: MA455

User Manual



Thank you for purchasing the Dayton Audio® MA455 Multi-Zone On-Wall 4 Channel Amplifier.

IMPORTANT SAFETY INSTRUCTIONS

1. Read these instructions and keep them for future reference.
2. Carefully follow instructions and warnings.
3. Do not use this device near water.
4. Clean amplifier housing only with a dry cloth.
5. Do not block any of the ventilation openings.
6. Do not install near any sources (including amplifiers) that produce heat.
7. Do not remove power cable grounding plug.
8. Prevent the power cable from being stepped on or pinched.
9. Unplug this unit during lightning storms or if not in use for an extended period of time. This device can be plugged into a surge protector or power strip, but should NOT be plugged into a UPS (uninterruptible power supply).
10. Refer all servicing to qualified service personnel.

WARNING: To reduce the risk of fire or electric shock, do not expose device to moisture.


WARNING: Ensure there is at least two inches of clearance on all sides of the amplifier for proper ventilation.

Important Safety Instructions

To reduce the risk of electric shock, do not remove cover. No user serviceable parts inside. Refer servicing to qualified personnel. To reduce the risk of fire and shock do not expose unit to rain or moisture. The unit should be connected to an earth grounded AC electrical socket. The unit should be operated in a well ventilated area. Minimum clearance is 2 inches.




PACKAGE CONTENTS




- 1 x Amplifier system
- 1 x Set of screws and accessories
- 1 x IR remote controller
- 1 x User manual

FEATURES AND CONNECTIONS



1. Speaker outputs connectors
2. IN/OUT connectors
3. IEC power input
4. Main power switch




APPLICATION




INSTALLATION

This device should be exclusively installed by a professional. All connections and hardware adjustments are inside the device, not accessible by the end user. For installation, please follow the instructions below:

1. Remove front panel cover (6 screws on top and 6 screws at the bottom)
2. Mount device on wall using accessories supplied in the package
3. Connect mains. **CAUTION: Must be done by qualified personnel! Turn OFF power switch**
4. Connect speakers




I/O Connections



The MA455 is designed to accept MIC level and LINE level on each channel.


1. RCA LINE level input
2. 1/4" Jack for LINE level input.
3. LINE/MIC level switch. Select the input used for this channel.
4. LINE OUT. LINE level RCA connector output. Independent for each channel, this output can be used to be connected to another amplifier if you need more output power.

Channel Section




5. Channel Volume Rotary Knob - Independent volume control for each channel
6. ZONE Selection - Select the zone the channel is assigned to. You can select one or many zones.
7. Bass & Treble Controls - Independent bass and treble control for each channel. **NOTE: This adjustment is accessible only by the installer, not the end user.**

Zone Section



8. Zone Volume - Independent zone output level adjustment.
9. Output Level Indicator - If led is fully lit, the output level is too high. Reduce output volume (8) or channel level (5). that the output level is too high. Reduce output level (8) or channel level (5).

Output Bass-Cut Section




10. Bass-cut Switch - Cut bass lower than 80 Hz on the output signal. This is required when small size speakers are used with restricted bandpass.

NOTE: This adjustment is accessible only by the installer, not the end user.

10

Internal Media Module



- 11. SD MMC port compatible SDHC
- 12. USB port for USB device (USB stick or USB hard drive (FAT32))
- 13. Large backlite LCD display
- 14. ZONE buttons : Select the ZONE, the internal media source will playback the music. You can select one or several zones.
- 15. Function buttons:

- MODE On/Off** Use this MODE button to select switch USB/SD or Bluetooth MODE. Long press on this button to turn ON/OFF the internal media source. If Bluetooth mode is selected, the Bluetooth logo will be displayed on LCD. The Media Player is waiting for pairing.
- /II / Folder** Play/Pause button, is used for selecting your files folders from the USB/SD device. Long Press on this button to access to the Folder function. Then use the buttons ◀◀ or ▶▶ to move UP and Down in the folder, press Folder button to select the file.
- ↺** Repeat button. Select your repeat MODE from «REPEAT ONE », «INTRO», «REPEAT ALL » and «RANDOM» function.
- ◀◀** SKIP Backward and internal media source Volume Down. Use this button to select your file into the folder, to change track or to access to internal volume by keeping the button pressed.
- ▶▶** SKIP Forward and internal media source Volume Up. Use this button to select your file into the folder, to change track or to access to internal volume by keeping the button pressed.

Remote Control

-
- The diagram shows a remote control with callouts 16 through 25. Callout 16 points to the POWER button. Callout 17 points to the STOP button. Callout 18 points to the MUTE button. Callout 19 points to the REPEAT button. Callout 20 points to the EQ button. Callout 21 points to the PLAY/PAUSE button. Callout 22 points to the TRACK SELECT buttons (1-9). Callout 23 points to the VOLUME buttons (left and right). Callout 24 points to the SKIP buttons (left and right). Callout 25 points to the MODE button.
- 16. POWER: Powers the unit ON/OFF
 - 17. STOP: Stops media playback
 - 18. MUTE: Mutes media playback
 - 19. REPEAT: Switch between Repeat one/all and Function folder
 - 20. EQ: Switch between 7 EQ presets: Normal/Rock/Pop/Classic/Jazz/Country/Bass
 - 21. PLAY/PAUSE:
 - 22. TRACK SELECT: Select track number to playback
 - 23. VOLUME: Volume down (left), volume up (right)
 - 24. SKIP: Play previous song (left), play next song (right)
 - 25. MODE: Switch between USB/SD and Bluetooth mode

SPECIFICATIONS

Model	MA455
Amplifier type	Class AB
Power Output (RMS)	4 x 55W @ 4Ω (all channels driven)
Media Player	USB / SD / Bluetooth / FM radio
Frequency response	20-20,000 Hz
MIC input sensitivity	-35 dB
MIC input impedance	2 KΩ
LINE input sensitivity	-3 dB
LINE input impedance	20 KΩ
THD	<0.1% @ 1 kHz, 0 dB
MIC S/N ratio	<75 dB rated output
LINE S/N ratio	<80 dB rated output
Tone correction	+/- 12 dB
LINE output	+3 dB
Power supply	110 or 220 VAC, 50/60 Hz
Dimensions	18.7" H x 15.1" x 3.7" D
Weight	18.7 lbs.

5-Year Limited Warranty
See daytonaudio.com for details



daytonaudio.com
tel + 937.743.8248
info@daytonaudio.com

705 Pleasant Valley Dr.
Springboro, OH 45066
USA

For technical support
please contact:
support@daytonaudio.com

