

# polk BOOM



BIT

OWNER'S MANUAL

**Polk BOOM— Ready for Anything™**

Enjoying music anywhere demands a product that's ready for anything. And Polk BOOM has that concept on lockdown and then some. Born on original motives with Southern California roots that run deep, Polk BOOM pushes the limits to deliver great sound for whenever you're on the go from an all-in-one speaker that's water-, dirt-, and shock-proof.

Designed with the adventurer in mind. Engineered to withstand the harshest elements. And built for durability over the long haul. It's these unique principles that propel your experience of sound to new levels. It's what inspires you to go big and move forward on the journey with your favorite music in tow—no matter what gets in the way.

**BIT**


**Bit—The World's First Wearable Speaker**

The Polk BOOM Bit is the world's first truly wearable *Bluetooth* speaker that immerses you in your own personal bubble of sound. Designed to clip securely to your clothing (ex. T-shirt collar, backpack, hat brim, etc.) and near your head, it seamlessly integrates with how you move, safely balancing all of your audio with your immediate surroundings. It features speakerphone capability and a standard USB for on-the-go charging—all housed in a ruggedly rubberized enclosure.

**Note:** Not recommended for clipping to anything more than .25" thick.

**How to Power On/Off Your Bit**

Press and hold the + and - buttons simultaneously until an audible cue is heard to indicate that it's powered on and searching for a device to pair with.



To turn off the Bit, press and hold the + and - buttons until an audible cue is heard. The Bit will power off.

**Note:** The Bit will automatically turn off after eight minutes if no *Bluetooth* connection is established between it and your phone, tablet or computer.

**Connecting Your Bit via Bluetooth**

If you have not paired your Bit to a specific device, the Bit will automatically go into pairing mode as soon as it powers on. Go into your phone's *Bluetooth* settings (make sure to enable *Bluetooth* as well) in order to connect the Bit to your device.

Next, locate the Bit on your *Bluetooth* device list and select Polk BOOM Bit. You will hear an audible cue that it has paired and the blue light will begin flashing every five seconds on your Bit.

**Note:** A battery icon also appears next to the *Bluetooth* icon at the top of your phone's screen, indicating the Bit's battery level.

**Controlling the Audio on Your Bit**

Play / Pause	Tap +/- buttons at same time
Volume Up / Down	Tap + or - buttons (audible cue sounds at max volume; mutes at lowest volume)
Forward Track	Hold + button for two seconds
Backward Track	Hold - button for two seconds.

**Note:** All settings can be adjusted through your phone.

**Taking Calls and Using Your Bit's Speakerphone**

If your Bit is paired to your phone and there's an incoming call, your music will pause and your ringer will sound through the Bit.

**Answer Call:** Hold + button for two seconds

**End Call:** Hold - button for two seconds

**Note:** Remember, you can still adjust the volume on the Bit while you talk.

**Charging Your Bit**

The Bit features a standard USB for super easy, on-the-go charging. Simply flip open the hinged cap and insert the Bit into any USB outlet.

The LED light on the Bit turns red while plugged in and charging. The red light will then turn off when your battery is fully charged.

It takes about two hours to fully charge your Bit, giving you three hours of uninterrupted music at half volume.

**Maintaining Your Seal**

Ensure that the hinged cap is covering the standard USB, fully pushed in and snapped to its original position, and flush with the body of your Bit.

**Factory Reset**

If you're having any connectivity issues, you may need to perform a factory reset of your Bit. To do that, press the +/- buttons at the same time for eight seconds. An audible cue will follow along with a distinct "beep" sound. You will notice the LED indicator flashing every two seconds and waiting to be discovered and paired in *Bluetooth* mode.

**Having issues with your BOOM Product?**

We want to hear about it.

1 Viper Way  
Vista, California USA 92081  
800-377-7655  
polkcs@polkaudio.com



Polk Audio, LLC  
1 Viper Way  
Vista, California USA 92081

[www.polkboom.com](http://www.polkboom.com)

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by BOOM is under license. Other trademarks or trade names are those of their respective owners.