





Loudspeaker Angle




PRE OUT
PREAMPLIFIER
LINE OUT



Connecting the loudspeakers




Loudspeaker Placement




Desktop Positioning


Tabletop Control




G Three




G Four and G Five




Corner



Against a wall




G Three



Low Bass -4 dB
Bass -4 dB

G Four and G Five




Low Bass -4 dB
Bass -4 dB

G Three



Bass -4 dB

G Four and G Five



Bass -4 dB

Using Tone Controls